

FLEXO ANILOX UNIVERSAL

Galaxy Flexo Anilox Universal has been specially developed for the daily manual cleaning of anilox rolls, printing plates and other machine parts that are contaminated with water-based or UV inks. In addition, Flexo Anilox Universal is also very suitable for use in ultrasonic cleaning machines.

Application: Suitable for both manual and ultrasonic application

Flexo Anilox Universal has very good cleaning properties, is completely water miscible and low foaming

Safe for, stainless steel, aluminium, ceramic, polyethylene (PE), polypropylene (PP)

Procedure to use: For manual application, dispense the Flexo Anilox Universal undiluted into a bucket or spray bottle. Then apply the cleaner to the surface to be cleaned using the sponge or polishing cloth. Leave the cleaner on for a few minutes and then rinse well with water.

For Ultrasonic application, dose the Flexo Anilox Universal undiluted into the tank of the machine. Heat the Flexo Anilox Universal to 40°C and place the contaminated parts in the machine. Start the washing program of the machine. Then rinse well with water.
(Refer to the machine's manual for optimal cleaning.)

Product parameters:	Appearance	Transparent green liquid
	Specific gravity	1.01 g/cm ³
	VOC	7.5 %
	pH	11.4 ± 0.5

Storage conditions: Store at room temperature conditions and in a well-ventilated area. Keep away from open fire and heat sources.

Shelf life: In unopened, original packaging, 12 months from manufacturing date

Packaging: 20ltr jerrycan

Version: 01-2012

The information provided in this technical data sheet is to inform our customers. A successful application depends on a variety of different factors. Therefore, the advice given in this technical data sheet cannot be used as basis for claims. Our recommendation is where possible to perform tests before entering production runs. We reserve the rights to change product characteristics because of technical progress, amendment of applicable law and mandatory production related needs.